



910103

## Tork Salubrin Gel Hand Sanitiser

Tork Salubrin Hand Sanitiser with 70% (w/w) denatured alcohol effectively kills microorganisms to help prevent the spread of infections. Effective against a variety of organisms, including enveloped virus. Ideal for everyday hand hygiene. The formula contains moisturising ingredients for a pleasant feeling on the hands. Suitable for use with Tork Liquid Soap Dispenser (S1).

- Certified effortless maintenance and intuitive refilling in less than 10 seconds
- Use biocides safely. Always read the label and product information before use.
- Conforms with EN 1500 and EN 14476 (all enveloped viruses, such as HIV, SARS Corona, HBV, HCV, influenza H1N1 and H5N1, etc.)
- Moisturising ingredients encourage good hand hygiene behaviour
- Choose push-button or arm-lever dispenser
- For hazard and precaution information, please refer to the Safety Data Sheet.

### Product certificates



## Product and delivery data

**System**  
S1

**Quality**  
Premium

**Colour**  
Transparent

## Delivery data

	Consumer units (CON)	Transport units (TRP)	Pallet (PAL)
<b>EAN</b>	7322541328423	7322541328430	7322541342160
<b>Packaging material</b>	Plastic	Carton	
<b>Pieces</b>	1	6 (6 CON)	480 (80 TRP)
<b>Transport units per layer</b>			20
<b>Layer per pallet</b>			4
<b>Gross weight</b>	907 g	5.7 kg	454.88 kg
<b>Height</b>	246 mm	260 mm	1203 mm
<b>Length</b>	91 mm	290 mm	1200 mm
<b>Width</b>	93 mm	196 mm	800 mm
<b>Net weight</b>	860 g	5.2 kg	412.8 kg
<b>Volume</b>	2.08 dm <sup>3</sup>	14.78 dm <sup>3</sup>	1.18 m <sup>3</sup>

## Compatible products



**560000**  
Tork Liquid and Spray  
Soap Dispenser



**560008**  
Tork Liquid and Spray  
Soap Dispenser



**511054**  
AD-A-Glance® for  
Tork Hygiene Stand



**511055**  
Tork Hygiene Stand



**511060**  
Tork Sanitiser Stand



**511049**  
Floor Protector for  
Tork Sanitiser Stand



Think ahead.

# Tork Salubrin Gel Hand Sanitiser

## Technical data

<b>Ingredients</b>	Active ingredient Ethanol 64g/100g Other ingredients Alcohol Denat, Aqua, Glycerin, PVM/MA Decadiene cross-polymer, Aminomethyl propanol, T-butyl alcohol, Isopropanol (6.4g/100g)
<b>pH</b>	pH ~7.5
<b>Method Of Use</b>	Ensure hands are clean and dry before use. For general hygiene: Apply 1-2 doses (entire hand should be wetted) and rub well until dry (15-30 seconds). For disinfection according to EN 1500: Apply enough product to wet all parts of the hands for 60 seconds. Rub until dry
<b>Shelf Life</b>	Expiration date of 36 months after production is printed on inner packaging. Store in original container. Protect product from excessive sunlight. Avoid temperature extremes and store between 4°C and 30°C.
<b>Handling Instructions</b>	Use disinfectants safely. Always read the label and product information before use. Avoid contact with eyes. In case of contact with eyes, rinse immediately with plenty of water and seek medical advice. For more information, please refer to the Safety Data Sheet. May discolour certain fabrics or surfaces.
<b>Regulatory Compliance</b>	The biocide products commercialised under the Tork brand are in compliance with the Biocidal Product Regulation (EU) No 528/2012 and are approved for human hygiene purposes. The products are registered and authorised in the respective countries, where the products are sold. The products are in conformity with the REACH regulation (EC) No. 1907/2006 and its amendments. All non-biocidal ingredients are in compliance with the Cosmetic Regulation (EC) No. 1223/2009 and are considered as safe for human health when used under normal or reasonably foreseeable conditions. The biocide products are manufactured in accordance with good manufacturing practices (GMPs).
<b>Registrations Biocides</b>	Norway (NO): 634195; Germany (DE): N-87109; Sweden (SE): 600951-8; Denmark (DK): PR-nummer: 4290819; France (FR): 62192; United Kingdom (UK); Austria (AT)
<b>Certification</b>	ISO 22716 (Good Manufacturing Practice); ISO 9001 (Quality Management System) & 14001 (Environmental Management)
<b>Safety Data Sheet</b>	For safe use and handling of the products, please follow the recommendations on the Safety Data Sheets. These are available on the Tork website in all required local versions according to legal requirements for each region (e.g. according to CLP for Europe).



Think ahead.

# Tork Salubrin Gel Hand Sanitiser

## Microbiological tests

	Test method	Test conditions	Test durations
<b>Bacteria</b>	EN 12791	Hygienic hand rub	60 sec
	EN 1276	Bacterical activity for food, industrial, domestic and institutional areas	30 sec
<b>Yeast and Fungi</b>	EN 1650	Yeasticidal activity in food, industrial, domestic and institutional areas	30 sec
<b>Viruses</b>	EN 14476	Virucidal activity in the medical area (All enveloped viruses, such as HIV, SARS, Corona, HBV, HCV, Influenza H1N1 and H5N1 etc.)	60 sec